MITSUBISHI ELECTRIC

LAN Control Utility
User Manual

Contents

Preparation/SetUp 2
- Preparation before using the network function 2
- Connection 2
- Installation 3
- Setting the IP address of the projector 5
  - When using a DHCP server 6
  - When not using a DHCP server 7
- Telnet setting 8
  - Setting the password (Password Setup) 9
  - Setting the display language of ProjectorView (language) 9
  - Setting the LAN control (LAN-Controlled Mode) 10
  - PJLink™ certification (PJLink certification Mode) 10
  - Save and exit 11

ProjectorView 12
- Using the ProjectorView 12
  - How to start up 12
  - VIRTUAL REMOTE controller 14
  - E-mail notification function 14
  - Initial setting 15

Support for the PJLink™ function 16

Preparation/SetUp

Preparation before using the network function

This projector is equipped with the network function to control and monitor the projector's operations using a Web browser and to send e-mail notification.
Before using the network function, perform the following three preparation steps.

(1) Setup of the application software "Projector-Control Device Installer"
(2) Setting of the IP address of the projector [*1]
(3) Setting of password, display language, LAN control, and PJLink™ certification using telnet.

[*1] When setting IP addresses for multiple projectors collectively or when setting an IP address for a ceiling-mounted projector after installation, check and take a note of combination of the projectors and the hardware addresses (MAC addresses) in advance. To check the hardware addresses (MAC addresses), perform step 2 on the page 5.

[Major functions]
Setting of the projector's IP address
Setting of password, display language, and LAN control
PJLink™ certification setting (Telnet function)
Startup of the controlling /supervising tool (ProjectorView) using the Web browser

[System requirements]

Supported OS	: Windows® 2000, Windows® XP (Microsoft® .NET Framework 1.1[*2] should be installed.)
CPU	: Pentium II 233 MHz or higher
Memory	: 128 MB or more
Free HDD space	: 32 MB or more
Web browser	: Internet Explorer Ver. 6.0 (Java Plug-in[*3] should be installed and Javascript should be enabled.)

[*2] How to install Microsoft® .NET Framework Version 1.1
(1) Download .NET Framework Version 1.1 (file named "dotnetfx.exe") from the download center on the Microsoft® Web site (http://www.microsoft.com/downloads/).
(When the file is unavailable from the above-mentioned URL, search for .NET Framework using Windows Update and access the download site found.)
(2) Execute the downloaded file named dotnetfx.exe.

[*3] How to install Java Plug-in
(1) Download J2SE v1.4.2 JRE from the JAVA download center on the Sun Microsystems Web site (http://java.sun.com/j2se/1.4.2/ja/download.html).
(When the file is unavailable from the above-mentioned URL, search for "J2SE download" using a search engine and access the download site found.)
(2) Execute the downloaded file.

- Microsoft or Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Pentium is trademark or registered trademark of Intel Corporation or its subsidiarie in the United States and other countries.
- PJLink is trademark applied for registration or registered trademark of Japan Business Machine and Information System Industries Association in japan, the United States and other countries.
- Other brand or product names are trademarks or registered trademarks of their respective holders.

Connection



- Use a straight-through category-5 cable for LAN connection.
- Don't touch the metal parts of the LAN connector and LAN cable because static electricity may be discharged from your body, causing damage to the projector.

Installation

Before starting installation, be sure to read "ReadMe.txt" contained in the CD-ROM.

1	Copy three files (Installer_Mitsubishi.msi, Setup.Exe, and Setup.Ini) contained in the Tools folder of CD-ROM to the hard disk of your personal computer.	
2	Double-click the file named Setup.Exe.	
3	When the following window appears, click Next.	

Mitsubishi Projector-Control DeviceInstaller
Welcome to the Mitsubishi Projector-Control DeviceInstaller Setup Wizard
The installer will guide you through the steps required to install Mitsubishi Projector-Control DeviceInstaller on your computer.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel
< Back
Next >

4	Select a folder to install the program, and click Next.	
5	Click Next.	
6	Installation starts. • The progress of the installation process is displayed as shown on the right.	
7	When the installation process is completed, click Close.	

How to remove Mitsubishi Projector Control Device Installer

Select [Start] - [Control Panel] - [Add or Remove Programs] - [Mitsubishi Projector - Control Device Installer] and click [Remove] (in the case of Windows® XP).

Setting the IP address of the projector

Before setting the IP address, check that the projector has been LAN-networked and turn on the main power of the projector.

1	Start the Projector-Control Device Installer. ・ Select [Start] - [All Programs] - [Mitsubishi] - [Mitsubishi Projector - Control Device Installer] (in the case of Windows® XP).	
2	Click the Search button. • Mitsubishi projector is recognized. (Note 1) When Mitsubishi projector isn't recognized, check the following. • The firewall function has been disabled. (When it has been enabled, search may not be conducted.) • The personal computer and the projector are on the same network. (For preventing unauthorized access.) • More than one Projector-Control Device Installer isn't running.	
3	Select a projector and click the Assign IP button.	
4	The Assign IP Address screen appears.	

• For automatic IP address setting by the DHCP server, go to page 6. For IP address setting without using the DHCP server, go to page 7.

When using a DHCP server

5	Select [Obtain an IP address automatically] and click Next.	
6	Click Next. • Check that the options are marked with check-marks as shown on the right. Keep them un-changed for normal use.	
7	Click Assign.	
8	Click Finish.	
9	Click the Search button. • Check the IP address.	

When not using a DHCP server

5	Select [Assign a specific IP address] and click Next.	
6	Enter a fixed IP address (for example, 192.168.0.1) and click Next.	
7	Click Assign.	
8	Click Finish.	
9	Click the Search button. • Check the IP address you set. (Note 2) When using the error/alert e-mail notification function described later, click the Assign IP button and set the subnet mask and default gateway correctly. • For the values of the subnet mask and default gateway, contact your network administrator.	

Telnet setting

Setting of password, display language, LAN control, and PJLink™ certification using telnet.
This section describes how to set the password, display language on the ProjectorView screen, LAN control, and PJLink™ certification that are necessary for the operation state control tool (commercially available) that uses the projector operation control/monitor tool ProjectorView and the industry standard PJLink™ protocol.

1	Start the Projector-Control Device Installer. • Select [Start] - [All Programs] - [Mitsubishi] - [Mitsubishi Projector - Control Device Installer] (in the case of Windows® XP).	
2	Press the + buttons on the left pane to expand the tree structure until the IP address you set appears.	
3	Click the Telnet Configuration tab.	
4	Select the Connect tab. Press the Enter key within 5 seconds after the message shown on the right appears. • When it passes 5 seconds without any operation on this screen, the screen is shaded and no key operation is accepted. In this case, click the Connect button again to continue setting.	
5	The setting menu appears.	

Setting the password (Password Setup)

1	Enter “0” and press the Enter key.	
2	Enter a new password (example: “proj2000“) and press the Enter key. (Default password is MITSUBISHI.)	

Setting the display language of ProjectorView (language)

1	Enter “1” and press the Enter key.	
2	Enter “0” for English or “1” for Japanese.	

Setting the LAN control (LAN-Controlled Mode)

1	Enter “3” and press the Enter key.	
2	To enable the e-mail notification function of Projector-View, enter 1 and press the Enter key. (Default is OFF (0).) (See pages 12 - 15 for ProjectorView function.)	

Setting the PJLink™ certification (PJLink certification Mode)

1	Enter “5” and press the Enter key. • When you don’t use PJLink™ protocol communication, skip this item. (See page 16 for PJLink™.)	
2	To enable the PJLink™ certification: Enter “1” and press the Enter key. (Default is ON (1).)	

Save and exit

1	Enter “9” and press the Enter key.	
2	The setting screen is shaded and the setting process completes.	

- Because the password, display language, LAN control, and PJLink™ certification are set using the telnet function, you can also set them on the command prompt window of the personal computer. Enter the following command and press the Enter key.

  > telnet IP address you set 9999

  [“>” shows a prompt.]

  When setting menu appears, perform the setting procedure as described above.

(Note 3)
Check that the port number “9999” isn’t blocked by the firewall.

ProjectorView

Using the ProjectorView

This section describes ProjectorView, a tool to control and monitor the projector's operations by a Web browser.
The major functions of ProjectorView are:

- Power on/off
- Input source switching
- State information indication (projector's name, temperature, lamp operation time, error/alert, etc.)
- E-mail notification in case of error/alert

How to start up

1	Start the Projector-Control Device Installer. • Select [Start] - [All Programs] - [Mitsubishi] - [Mitsubishi Projector - Control Device Installer] (in the case of Windows® XP).	
2	Expand the tree structure on the left pane until the IP address you set appears.	
3	Select the WEB Configuration tab.	
4	Click the External Browser button or Go button. External Browser button : The browser starts on a separate window. Go button : The browser starts on the Projector-Control Device Installer window. (Note 1) • You can start ProjectorView by directly entering the URL of the Web browser "http://IP address you set" instead of by clicking the External Browser button. • When you are using a proxy server, don't enable the proxy when accessing this IP address.	

5	The password input screen appears. Enter the password you set. • The default password is MITSUBISHI. (Note 2) If you input a wrong password three successive times, the Web browser is closed. In this case, repeat from step 1.	
6	The ProjectorView main screen appears. • Some buttons may not be displayed. In this case, select [Start] - [Control Panel] - [Java Plug-in] and disable the cache.	

[ProjectorView main screen]



Press to display the Setup window. (See page 15.)

Press to control the projector. For the functions of these buttons, see the user guide of the projector.

Failures in the projector are indicated with dots. When you place the mouse cursor to a dot, the indicated failure is described in the box at the bottom.

VIRTUAL REMOTE controller

Put a checkmark in the box of the Virtual remote enabled on the ProjectorView main screen, and click the VIRTUAL REMOTE button. The following Virtual Remote window appears.

For the functional descriptions of each button, see the user manual of the projector.

E-mail notification function

In case of an error or abnormality in the projector, e-mail notification is automatically sent to the designated address to notify of the error or abnormality.

To use this function, perform the following steps.

1 Enable the LAN control function. (See page 10.)

2 Set the SMTP IP address, E-mail address, E-mail host, and E-mail from.

Once the above-mentioned items are set, the e-mail notification function remains enabled even when the browser (ProjectorView screen) is closed.

Example of notification: Alert on lamp life end

ProjectorView Alert:
The lamp has reached its maximum usage. Replace the lamp and reset lamp counter. See user guide for complete instructions.

Projector name : abc
Projector model : XD2000U
Projector location : 10Factory-5F
Serial number : 12345
Operating hours : 2146 hours and 43 minutes
Lamp hours : 5000 hours and 0 minute
Installation date: 2005/06/02
Last lamp replacement date: 2005/07/15
Last maintenance date: 2005/08/03

(Note 3)

- In case of a command error, e-mail notification isn't sent.
- When the LAN control is enabled, serial RS-232C commands may not be transmitted.
- You can't control the LAN/serial RS-232C commands for about 10 seconds after turning on the main power of the projector.
- When commands for LAN control and for RS-232C control are issued at the same time, the LAN control command overrides the RS-232C control command.
- While a test pattern is displayed or a password is entered, you can't change the lamp mode and enable and disable the MUTE function.
- Response may be delayed depending on the operating state of the projector.
- The DHCP mode may not operate with certain devices (routers etc.).
- When you turn on the projector by pressing the ON/OFF button on the ProjectorView main screen, other commands are not accepted for about 1 minute.

To use the e-mail notification function, configure the initial settings in advance as described on the next page.

Initial setting

To load information on the projector such as model name and lamp operating time, set the projector data in advance. Click the SETUP button on the ProjectorView main screen. The Projector Setup screen appears. Enter data according to the description of each setting item.



(Note 4)
You can't change the Projector model, Serial number, Operating hours, and Lamp hours.

Each setting item is described as follows:

Projector name*	Name to identify the projector
Projector model	Model name of the projector
Projector location*	Location of the projector
Serial number	Serial number of the projector
SMTP IP address*	IP address of the SMTP server used for e-mail transmission (Example: 192.168.0.1)
E-mail address*	e-mail address to receive alert notification e-mail (Example: administrator@XXX.XXX.XXX)
E-mail host*	User-defined string displayed at the Internet header of e-mail message (Example: user)
E-mail from*	Sender of alert notification e-mail (Example: PJView@XXX.XXX.XXX)
Operating hours	Cumulative projector operating time
Lamp hours	Cumulative lamp operating time calculated on the "Low" lamp mode basis.
Installation date*	Date when the projector was installed
Last lamp replacement date*	Date when the lamp was last replaced
Last maintenance date*	Date when the projector was last maintenanced
Virtual remote enabled	Display or hide the virtual remote controller (Check the box to display.)

*) For data entry, use alphanumeric characters and symbols (+ - / = @ * _ ! ? . , ; : # $ % & ( ) | < > [ ] { } " ').

(Note 5)
When the "Standard" lamp mode is selected, the indicated lamp operating time may exceed the indicated operating time. For example, when you use the projector in the "Standard" mode for 2 hours, the lamp operating time is indicated as 5 hours.

Support for the PJLink™ function

This projector supports standard protocol PJLink™ for projector control and you can control and monitor projector's operations using the same application among projectors of different models and different manufacturers.

To use this function, perform the following steps.

1 Enable the LAN control function. (See page 10.)

2 Set the PJLink™ certification properly according to the setting of the PJLink™ application to be used. (See page 10.)

Supported commands

The table below shows commands to control the projector using the PJLink™ protocol.

Command	Description	Remark (Parameter)
POWER	Power control	0 = Standby 1 = Power on
POWR?	Inquiry about the power state	0 = Standby 1 = Power on 2 = Cooling down 3 = Warming up
INPT	Input switching	11 = RGB1 12 = RGB2 21 = VIDEO 22 = S-VIDEO 31 = DVI-D
INPT?	Inquiry about input switching	
AVMT	Mute control	30 = Video and audio mute disable 31 = Video and audio mute enable
AVMT?	Inquiry about the mute state	
ERST?	Inquiry about the error state	1st byte: Fan error, 0 to 2 2nd byte: Lamp error, 0 to 2 3rd byte: Temperature error, 0 to 2 4th byte: Cover open error, 0 to 2 5th byte: Always 0 6th byte: Other error, 0 to 2 0 to 2 mean as follows: 0 = No error detected, 1 = Warning, 2 = Error
LAMP?	Inquiry about the lamp state	1st value (1 to 5 digits): Cumulative lamp operating time 2nd value: 0 = Lamp off, 1 = Lamp on
INST?	Inquiry about the available inputs	The following value is returned. "11 12 21 22 31"
NAME?	Inquiry about the projector name	The projector name set on the ProjectorView Setup window is returned.
INF1?	Inquiry about the manufacturer name	"MITSUBISHI" is returned.
INF2?	Inquiry about the model name	"XD2000U" or "XD1000U" is returned.
INF0?	Inquiry about other information	
CLSS?	Inquiry about the class information	"1" is returned.

- This projector is fully compliant to the specifications of JBMIA PJLink™ Class 1. It supports all the commands defined by PJLink™ Class 1, and the compliance has been verified with the PJLink™ standard specifications Version 1.0.

(Note 1)

- The above-mentioned control may not be performed correctly or the monitoring data may not be obtained correctly in the following conditions:
  - During standby.
  - During input source switching.
  - During command processing.
  - Before the splash screen disappears after the power is turned on.
- Use 1 controller to control/monitor 1 projector.
- When you monitor the projector's operating state regularly using this function, issue inquiry commands at intervals of at least 1 minute.
- For the specifications of PJLink™, access to the Web site of Japan Business Machine and Information System Industries Association (JBMIA).

[Notes on Instant Shut Down]

Instant shutdown of the projector during control using the network function may cause ProjectorView to fail to display data correctly.

- The operating time and temperature may not be displayed correctly. In this case, close the browser, recognize this projector using Mitsubishi Projector Control Device Installer, and then start the browser again. (Refer to “How to start up” of ProjectorView.)
- When you use the e-mail notification function only, no special action is required.

[Terms and definitions]

For detailed descriptions, see commercial books.

Term	**Definition**
DHCP	Abbreviation for Dynamic Host Configuration Protocol. This protocol automatically assigns IP addresses to networked devices.
Gateway	A server (or router) to communicate across networks (subnets) that are divided by subnet mask.
IP address	Numerical address to identify networked computers.
MAC address	Abbreviation for Media Access Control address. MAC address is a unique ID number assigned to each network adapter, based on which data are sent and received between network adapters.
Subnet mask	A value to define the number of bits used for a network address of a divided network (or subnet) in an IP address.
Telnet	A virtual terminal protocol to log in to and control a remote computer.
URL	Abbreviation for Uniform Resource Locator. URL is a unique Internet address of each Web page.